


# Friction Hinges

## Measuring Friction Hinges

---

### 1. Measure Hinge Length




#### A. Length


**B. Width:** Either: 17mm-18mm (Standard) or 15mm-16mm (Slimline).

**C. Measure the Stack Height:** Either 13mm (Standard) or 17mm (Deep).

### 2. Check the Hinge Type



**Top Hung**



**Side Hung**

**Egress:** Opens up to provide emergency egress in the case of fire.

**Restricted:** Restricts the opening angle for safety.

**Easy Clean:** Allows access to the outside of the sash for cleaning.