Tilt & Turn

Tilt & Turn Gearing

Information for Ordering:



1. Window Material

UPVC, aluminium, wooden or timber/ali clad.

2. Revealed or Concealed

When the window is in the closed position, if you can see gearing on the hinge side this is a revealed system (sometimes called 'face fixed').

3. Handing

Looking at the window from the inside, if the handle is on the left it is RIGHT HAND gearing.

4. Tilt First or Turn First

The majority of windows in the UK are tilt first. To determine, start with the window in the closed position and note whether the first movement is for it to tilt or to turn.

5. Sash Size

Measure the rebate size (the smaller dimension taken from the inner edge of the sash opener that the gearing fits into). When this is not possible, provide the overall sash size.

6. Gearing Manufacturer

Check the main drive gear for any stamping.

7. Eurogroove Position

Measure from the centre of the eurogroove to the edge of the sash, also called the 'axis' - this will be either 9mm or 13mm

8. Make of Profile

Remove and check the back of the keeps.